

Enclosure Loses Power During Disk Insertion

Symptom

A NonStop S-series system enclosure with a power shelf loses power during disk drive insertion.

Version

All.

Problem

You attempted to insert several disk drives into slots simultaneously, or you inserted a disk drive too rapidly.

Fix

Apply power to the enclosure, and restart and recover any failed operations.